

2020-up HD TriGlide CVO Connector Retro-fit

The CVO model TriGlides have different wiring at the tail light flange.

The BROWN wire in the BAL connector needs to be moved over one pin (to the currently empty slot).

This can be done with the Tyco/TE connector tool, a small jeweler's flat screwdriver, or even a straight pin. There is a locking flap with two clips on the sides of the connector & then there is a locking tab inside that holds the terminal. Once released, slide the terminal out & over one position, keeping the orientation so that it will slide back in easily. You will hear a "Click" when it is locked in. Close the locking flap on the wire exit side to complete.

SEE PICTURES BELOW

